



**JENSEN 541 USING FA2706/101 FILTER
HEAD**

**OIL FILTER ADAPTOR FITTING
INSTRUCTIONS**

Please read all the instructions before starting work on your car.

The kit contains:

- Large diameter rubber seal
- Small o-ring
- Aluminum adaptor plate
- Extension bolt
- Canister bolt



(This diagram is for illustration purposes)

Remove the original filter bowl and its sealing ring (which may be stuck in the filter head). Fit the large diameter o-ring supplied into the groove in the filter head.

Remove the central splash plate (a large steel “washer” and the felt washer if one is there).

Place the smaller o-ring over the central spigot in the filter head and place the adaptor plate in position. Screw in the adaptor bolt and extension by hand. Using a 1" AF socket tighten the adaptor bolt fully (but do not over tighten).

When fitting a new spin-off filter always fill it with oil before screwing it on to the adaptor. Always check for leaks after fitting a filter and after fitting the adaptor for the first time.

Use a Fram PH2857A, or similar oil filter. Remember to grease the square seal on the filter before fitting.