



LANCIA FLAMINIA OIL FILTER ADAPTOR FITTING INSTRUCTIONS

Remove the canister and old oil filter. Remove the rubber seal which sits in a groove in the filter head. Place a tommy-bar through the hole in the central mounting boss (this is the steel part into which the canister retaining bolt screws) and unscrew the boss. Remove the boss, the splash plate (if fitted) and the felt washer which sits under the splash plate.

Place the new rubber seal supplied with this kit into the groove in the filter head. Place the adaptor plate in position so that the narrow lip locates in the groove and sits up against the seal. Insert the locating bolt (and copper washer) supplied with this kit through the plate and screw it up finger tight, making sure that it seats properly against the seal. Use a 1" AF socket and tighten the bolt fully.

You are now ready to fit a spin-on filter to your Jaguar. Use a Fram PH2957, Coopers Z88, or similar high quality filter. Remember to fill the filter with oil before fitting and change it at the recommended intervals.