



AUSTIN HEALEY 3000 OIL FILTER ADAPTOR FITTING INSTRUCTIONS

Remove the complete filter head assembly from the engine block. Make sure that the exposed surface is clean and that there are no traces of old gasket, sealant etc. Ensure that all the holes in the adaptor will match up with the holes on the engine block. You may wish to use sealant or a gasket when fitting the adaptor. Place the adaptor block in position and insert the locating bolts through the plate into the block. Gently tighten the bolts making sure that the adaptor plate is seating correctly against the block. Finally tighten the two bolts fully. The use of Loctite on the bolts is recommended.



You are now ready to fit a spin-on oil filter to your Austin Healey. We recommend a Crosland 357 or similar high quality filter. Always grease the sealing ring of the filter before fitting as this helps to remove it later. Always check for oil leaks on initial start-up. Observe the original filter change intervals. Never tighten a spin-on filter with a filter removal tool.

Now that you have fitted a Flexolite adaptor to your car it will be easy to fit an oil cooler. For details on this and other Flexolite products - braided stainless steel flexible brake and clutch hoses, fuel line, fuel filters, etc - contact Flexolite.