

Handcontrol Fitting Instructions

Only use 30% glycerine / 70% water or an antifreeze & water mix.

DO NOT use brake fluid, mineral oil, ATF etc.

The handcontrol unit is pre filled & bung inserted.

Fill the telecontrol system from the pump reservoir unit and bleed as you would a brake system. Only attach pipework to handcontrol unit when all pipework is full this is to stop air entering the bag as this is usually the highest point.