



ROVER P4 OIL FILTER ADAPTOR

FITTING INSTRUCTIONS

Please read all the instructions before starting work on your car.

The kit contains:

- Large sealing ring
- 2 x Small o-rings
- Bolt 3/8
- Copper washer
- Extension tube
- Aluminium adaptor plate
- Bolt 948
- Oil filter



(This diagram is for illustration purposes only)

Remove the filter bowl and the old filter. Remove the filter bowl retaining bolt, the large oil seal around the edge of the filter head, and the small rubber seal in the centre of the filter head.

Fit the new large rubber seal supplied with this kit in the groove in the filter head. Place one of the rubber o-rings in the filter head and the other in the shallow central groove in the oil filter adaptor plate. Place the ordinary 3/8 bolt (and copper washer) in the hole in the filter head. Place the adaptor plate in position making sure that none of the seals has moved. Insert the locating bolt through the adaptor plate and screw the two bolts and extension tube together. Tighten using the correct spanners or sockets (we recommend the use of Loctite).

You are now ready to fit a spin-on filter to your Rover. Use a Crosland 2022, or similar high quality filter. Don't forget to grease the oil seal in the filter before fitting. Observe the manufacturer's change intervals.

Also available for Rovers: braided stainless steel flexible brake and clutch hoses, fuel lines and pressure gauge lines, fuel filters, oil coolers etc.